



Analysis of Beryllium samples at AWE

Bhavna Vara

Bhavna.Vara@awe.co.uk

www.awe.co.uk

Spring BHSC meeting 2013, ORAU - ORISE

Any reference to products, companies, persons or organisations is for information purposes only and does not represent any form of endorsement or criticism. Opinions expressed here are those of the author only and do not represent those of AWE.

Background.

- Previous presentations have considered the management of Be at AWE, and the collection of IH related data.

- This presentation considers:
 - Types of sampling at AWE,
 - The range of techniques used to analyse Be samples, and
 - A feasibility study on a new analytical technique - Microwave Plasma – Atomic Emission Spectrometry.

Types of Sampling.

- There are a range of sampling methods for beryllium at AWE;
 - Personal Air Samplers
 - Stack samples
 - Smear samples
 - Static Air samples

- Nose blows samples
- Wound monitoring swabs

Preparation Methods.

- Different types of preparation for the various types of samples:
 - PAS, SAS and smear samples:
 - paper filters – leached in 0.1% w/v potassium hydrogen sulphate: 2%v/v nitric acid solution.
 - glass fibre filters – leached in 0.1% w/v potassium hydrogen sulphate: 2%v/v nitric acid solution and centrifuged before analysis.
 - Stack samples:
 - paper filters – leaching in nitric acid and perchloric acid.
 - glass fibre filters – leaching in nitric acid and centrifuged.

Preparation Methods

- Wound Monitoring samples:
 - cotton bud swab – digested in nitric acid, perchloric acid and 0.1% w/v potassium hydrogen sulphate: 2% v/v nitric acid solution.
- Nose blow samples:
 - tissue samples – nitric acid and 0.1 w/v potassium hydrogen sulphate: 2% v/v nitric acid.

Comparison of Techniques

Technique	Flame Atomic Absorption Spectrometry (F-AAS)	Graphite Furnace Atomic Absorption Spectrometry (GF-AAS)	Inductively Coupled Plasma – Optical Emission (ICP-OES)	Inductively Coupled Plasma – Mass Spectrometry (ICP-MS)
Flame	Combustion air / acetylene	Combustion Nitrous oxide / acetylene	Argon plasma	Argon plasma
Limit of Detection (LOD)	<1 µg/L	0.05 µg/L	0.2 µg/L	1 – 10 ng/L
Linear Range	10 ³	10 ²	10 ⁵	10 ⁵
Precision	Short term 0.1 – 1%	Short term 0.5 – 5%	Short term 0.3 – 2%	Short term 1 – 3%
			Over 8 hours 2 – 5%	Over 8 hours < 5%
Interferences	Chemical	Spectral	Spectral	Spectral and ionisation

NB: ICP-MS is available, but not routinely used for Be sample analysis.

Analytical techniques used.

- Personal Air Samplers – Flame AAS
 - Static air samplers – Flame AAS
 - Stack samples – graphite furnace AAS
 - Smear samples – Flame AAS / ICP-OES
-
- Nose blows samples – Flame AAS
 - Wound monitoring swabs – Flame AAS

Microwave Plasma – Atomic Emission Spectrometry – Conditions.

- Potential replacement technique for Flame AAS.
- Six samples submitted for feasibility study with Agilent Technologies.
- Instrument was set up using a primary wavelength of 234.861 nm.
- Glass cyclonic spray chamber used for sample introduction in order to minimise signal to noise ratio.
- A 30 second integration period with two replicate samples in order to obtain best detection limits.
- Calibration standards range – 0 – 100 $\mu\text{g/L}$ (2% nitric acid matrix).



Microwave Plasma – Atomic Emission Spectrometry – Results.

- Recovery of spiked Be sample on filter paper:
 - at 25 $\mu\text{g/L}$ – 101.88%
 - at 0.5 $\mu\text{g/L}$ – 103%
- Limit of detection – 3x standard deviation of 10 blank samples (2% nitric acid matrix):
 - 0.087 $\mu\text{g/L}$
- Low level precision – 10 replicates of low standard
 - 4.31% rsd

Microwave Plasma – Atomic Emission Spectrometry – Advantages.

- Better sensitivity and detection limits from feasibility study.
- Can make a cost saving – use of site supplied nitrogen.
- Eliminating the use of flammable and oxidising gases
 - (nitrous oxide and acetylene).
- Easy to use software, low maintenance of equipment.
- Can do multi-elemental analysis
 - Feasibility study included Trade Waste samples (MP-AES Vs ICP-OES)

Summary.

- Full range of analytical techniques available for IH and regulatory sampling.
- Offsite labs used to undertake non-core business eg core sampling for decommissioning.
- Commissioning of a Microwave Plasma – Atomic Emission Spectrometer is underway.
- Intention to achieve UKAS accreditation for our Be analysis techniques.



Questions?